




VIDEO TUTORIAL
of the installation



CLEANING &
MAINTENANCE

Components provided in the box • Componenti forniti nella scatola • Composants fournis dans la boîte • Componentes proporcionados en la caja • Komponenten im Lieferumfang enthalten


1x



ABSECOVER

Components provided in separate boxes • Componenti forniti in scatole separate • Composants fournis dans des boîtes séparées • Componentes suministrados en cajas separadas • Komponenten werden in separaten Kartons geliefert

1x




DISPENSER CARTRIDGE

1x



1x



1x



2x

2x





BRACKET KIT

1



INSERT THE CARTRIDGE INTO THE ABS ECOVER, PAYING ATTENTION TO THE DIRECTION OF THE PUMP

2



INSERT THE ABS ECOVER WITH THE CARTRIDGE INTO THE BRACKET ALREADY INSTALLED ON THE WALL





VIDEO TUTORIAL
of the installation





CLEANING & MAINTENANCE

3




**SLIDE THE ABS ECOVER
AND THE CARTRIDGE UNTIL THEY LOCK
INTO PLACE (CLICK!)**

**OPEN THE PUMP BY TURNING IT
CLOCKWISE TO THE CORRECT POSITION**



4

**DO NOT TURN THE PUMP
COUNTERCLOCKWISE**



5

change the cartridge

- 1. CHECK THE LEVEL OF THE CARTRIDGE:**
If you can see the bulk level near the bottom of the ABS ECOVER slot on the side, it's time to change the cartridge!
- 2. TO REPLACE THE CARTRIDGE:**
 - Use the key to open the ABS ECOVER
 - Remove it from the bracket
 - Rotate the pump to the initial position so that the cartridge comes out of the ABS ECOVER
 - Replace the empty cartridge with a new one

